

rtc TYPE **EBFM 90**

Elbow 90° / Winkel 90°



Adapter / Nippel

Material: Brass - Messing



Order No / Bestellnr.

Male
Aussengewinde

Female
Innengewinde

EBFM 10 - 90	BSP 1/8	BSP 1/8
EBFM 13 - 90	BSP 1/4	BSP 1/4
EBFM 17 - 90	BSP 3/8	BSP 3/8
EBFM 21 - 90	BSP 1/2	BSP 1/2
EBFM 26 - 90	BSP 3/4	BSP 3/4
EBFM 33 - 90	BSP 1	BSP 1
EBFM 42 - 90	BSP 1-1/4	BSP 1-1/4
EBFM 48 - 90	BSP 1-1/2	BSP 1-1/2
EBFM 60 - 90	BSP 2	BSP 2

rtc TYPE **EBFM 45**

Elbow 45° / Winkel 45°



Adapter / Nippel

Material: Brass - Messing



Order No / Bestellnr.

Male
Aussengewinde

Female
Innengewinde

EBFM 10 - 45	BSP 1/8	BSP 1/8
EBFM 13 - 45	BSP 1/4	BSP 1/4
EBFM 17 - 45	BSP 3/8	BSP 3/8
EBFM 21 - 45	BSP 1/2	BSP 1/2
EBFM 26 - 45	BSP 3/4	BSP 3/4
EBFM 33 - 45	BSP 1	BSP 1
EBFM 42 - 45	BSP 1-1/4	BSP 1-1/4
EBFM 48 - 45	BSP 1-1/2	BSP 1-1/2
EBFM 60 - 45	BSP 2	BSP 2